

# Set Roll Length

The FloorRight user can setup roll lengths while setting up a new material or set roll lengths after the rooms have been drawn. In FloorRight 11.2 an option was added called “In Order”.

By: Mical Santiago

In FloorRight 11.2 two new settings were added when setting up roll lengths.

- Best Fit
- In Order

The first option “Best Fit” allows FloorRight to fit the pieces on the roll and the user manually sets the roll lengths.

Best fit calculates material used and shows a lower waste percentage. This is the same way FloorRight has calculated rolls in the past.

The second option “In Order” places the cuts in the order the user has moved them on the roll. “In Order” also allows the user to move cuts from one roll to another.

“In Order” calculates waste based on how many rolls are used so “In Order” shows a higher waste.

In the Job estimate screen if “In Order” is chosen the user can change the “Based On” from “Material Area” to “Roll Area”. The waste will be lower like the “Best Fit” option.



Setup roll length:

1. When setting up a new material or previously created material click “Roll Options” at the bottom to set a roll length.

Material

Basic Attributes	
Color	<input type="color"/>
Fill Style	Solid
Material Type	C-1
Style/Name	C-1
Color/Desc.	C-1
Pat. width	0'
Pat. length	0'
Pat. drop	0'

Advanced Attributes	
Layout Options	
Roll Options	
Use default roll options	<input type="checkbox"/>
Default roll length	150'

Import      OK      Cancel

2. Uncheck “Default roll length” and then type in the new roll length. Then click “OK”.

Roll Lengths

SV-2 | SV-1

SV-2 375' / approx 344' 9"

	Dye lot	ID / Name	Length
	- Default	~344' 9" need 375' available	
1			125'
2			125'
3			125'
	-		

Cut allowance between drops: 0' 3"

Use stock cut allowance between drops

Roll use

Best fit  In order

Default roll length: 125'

3. After drawing rooms click “Layout” at the top of FloorRight and left click “View seams/stock layout” or click the icon on the toolbar.





5. Check “Best Fit” at the bottom if you need to manually enter roll lengths and begin to type in the length in each cell.

Roll Lengths

SV-2 | SV-1

SV-2 395' / approx 344' 9"

	Dye lot	ID / Name	Length
	- Default	~344' 9" need	395' available
1			45'
2			75'
3			75'
4			125'
5			75'

Cut allowance between drops: 0' 3" Delete

Use stock cut allowance between drops Reset

Roll use

Best fit Default roll length: 75'

In order

Show Roll Allocation OK Cancel

6. Check “In order” so FloorRight will automatically assign how many rolls the material needs.

Roll Lengths

SV-2 | SV-1

SV-2 375' / approx 344' 9"

	Dye lot	ID / Name	Length
	- Default	~344' 9" need	375' available
1			75'
2			75'
3			75'
4			75'
5			75'

Cut allowance between drops: 0' 3" Delete

Use stock cut allowance between drops Reset

Roll use

Best fit

In order

Default roll length: 75'

Show Roll Allocation OK Cancel

7. Enter a stock cut gap if the project requires a distance between each cut.

Roll Lengths

SV-2 | SV-1

SV-2 375' / approx 344' 9"

	Dye lot	ID / Name	Length
	- Default	~344' 9" need	375' available
1			75'
2			75'
3			75'
4			75'
5			75'
	-		

Cut allowance between drops:

Use stock cut allowance between drops

Roll use  
 Best fit  
 In order

Default roll length:

8. Left click “Show Roll Allocation” on the bottom left and the user will see the rolls in the seam view.




Once the user has setup rolls they can print the rolls to a “Roll Report” to show the installers how many rolls are needed and which cuts go with which roll.



Print a roll report:


1. Click File at the top of FloorRight. Move the cursor down to Quick Report and left click "Rolls".



The screenshot displays a software application window with a menu bar (File, Edit, Defaults, Job, Tools, Drawing, Layout, View, Digitizer, Help) and a toolbar. The 'File' menu is open, showing options like New, Open..., Save, and Print. The 'Quick Report' option is highlighted, and its sub-menu is open, showing 'Rooms', 'Stock', 'Stock Cuts', 'Rolls', 'Preview Rooms', 'Preview Stock', 'Preview Stock Cuts', and 'Preview Rolls'. The 'Rolls' option is highlighted. The background shows a floor plan with dimensions like 14'6", 9'11", 8'7", and 4'1". A table of roll dimensions is visible at the bottom right.

6'	6'	6'	6' 3"	6'			
6'	6'	6'	6'	6'			
6'	6'	12'					
6'	6'	21.115'	6'	4' 4"	6'	6'	
6'	6'	6'	6'	6'	6'	6'	4' 11"

2. Click on “Rolls” then check which pages you need to print to PDF or paper.



3. Then choose a PDF writer or printer to print the Rolls report to and click “start”.

FloorRight Report Options

Set report options

Print target

Universal Document Converter Change...

Direct to... Printer Options...

Save options permanently

Options

First page: 1 Copies: 1

Pages:


All

Page range(s)

(Enter pages or ranges, separated by comma if necessary, e.g. '1,3-4,10-')


Print: All selected pages

? Start Cancel



- (A) 6' x 17' 10" (@ 0') New room 54 (5)
- (B) 6' x 18' 2" (@ 17' 10") New room 171 (8)
- (C) 6' x 16' 4" (@ 36') New room 172 (9)
- (D) 6' x 10' 7" (@ 52' 4")
  - New room 6 (1-2)
  - 10' 1" E
  - 0' 8" S
  - 0' 3" E
  - 3" S
  - 0' 3" W
  - 2' 4" S
  - 10' 1" W
  - 6" N
- (E) 4' 11" x 6' 1" (@ 62' 11")
  - New room 14 (3)
  - 5' 10" 90.46°
  - 4' 11" S
  - 5' 10" W
  - 4' 11" N
- (F) 6' x 5' 9" (@ 69') New room 76 (13)

# The cut gap is included in each cut.



- (A) 6' x 17' 10" (@ 0') New room 54 (5)
- (B) 6' x 18' 2" (@ 17' 10") New room 171 (8)
- (C) 6' x 16' 4" (@ 36') New room 172 (9)
- (D) 6' x 10' 7" (@ 52' 4")
- New room 6 (1-2)
  - 10' 1" E
  - 0' 8" S
  - 0' 3" E
  - 3' S
  - 0' 3" W
  - 2' 4" S
  - 10' 1" W
  - 6' N
- (E) 4' 11" x 6' 1" (@ 62' 11")
- New room 14 (3)
  - 5' 10" 90.46°
  - 4' 11" S
  - 5' 10" W
  - 4' 11" N
- (F) 6' x 5' 9" (@ 69') New room 76 (13)



For and questions about setting  
up rolls please contact  
[frsupport@pacific-solutions.com](mailto:frsupport@pacific-solutions.com).

A large, stylized blue wave graphic that curves across the middle of the slide, framing the text "The End.".

**The End.**